SHARP

OPERATION MANUAL



HOT & COLD WATER DISPENSER

MODEL SB-210
SB-210S

CONTENTS

	PAGE
SAFETY INSTRUCTION	10 - 11
DESCRIPTION OF PARTS	12
SPECIFIC INFORMATION	12
INSTALLATION GUIDES	13
HOW TO USE HOT & COLD WATER DISPENSER	13 - 14
STEPS TO FILL WATER INTO THE UNIT	14
CLEANING AND MAINTENANCE	15
INITIAL INSPECTIONS	16
TESTING FOR WATER LEAK FROM TANK COOLER	16

Please see the date of manufacture marked on the product

Thank you for your trust in products of Thai City Electric Co., Ltd. In order to use hot & cold water dispenser in efficiency way. Please read the instructions manual carefully before using this appliance.

REV.1-2566

SAFETY INSTRUCTION

Please read the warning and instruction for use carefully before using this appliance and comply strictly for your own safety and to prevent the damage that may occur on your property.

- The ground wire must be installed with the hot & cold water dispenser.
- To equip with electrical leakage protection device such as ELCB is recommended.
- Be sure to install the unit at non electrical induction and dry area. Such as non metal floor and always keep the floor unwet.
- Keep the unit be checked by the authorized service center every 6 months is recommended.



WARNING

1. Never share the wall outlet with other appliances.



2. Do not unplug the unit during the night time because this unit has automatic temperature control.
3. Do not plug in while the hand is wet as it may cause injury from electrical leakage.
4. Water temperature is approximately 80-95 celsius degree. Therefore, please operate the unit carefully as the water may burn your skin.

INSTRUCTION FOR USE

1. If the power cord or plug is damaged. The power cord must be replaced by the manufacturer, its aftersales service or similarly qualified persons in order to avoid a hazard.
2. If the unit is malfunctioned, do not fix it by yourself, for your safety and the efficiently use of the unit, please contact SHARP service center in your area.
3. Avoid using mineral water, tea or other fluids than pure water with the unit, as it can cause plaques in the hot water bucket and can be clogged in the hot water supply pipe.
4. This appliance is not intended for use by persons (including children) with reduced physical,sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
5. Children should be supervised to ensure that they do not play with the appliance.
6. Avoid using fill the cooler tank with water of temperature higher than 35°C because it cause the compressor to work hard as well.
7. In case of fluctuated power supply (you may notice on blinking or less brightness of lamp), the unit must be plugged off.
8. Before plug in the unit may be placed horizontally during transportation; therefore, you should place the unit vertically for approximately 24-48 hours before use so that the refrigerant in the compressor could flow back to a stable level. Then plug in the unit.
9. Always hold the plug tightly while plug in or unplug. Do not pull or surge the electricity wire as the wire may be damaged.
10. If the unit is turned off by unplug, when turn on the unit again, please wait at least 3 minutes to prevent the unit from being damaged.

DESCRIPTION OF PARTS



SPECIFIC INFORMATION

Model	SB-210	SB-210S
Rated voltage (V)	220	
Rated frequency (Hz)	50	
Power consumption (Heater) (W)	610	
Hot water capacity (Liters/Hr)	6	
Cold water capacity (Liters/Hr)	4	
Cooling agent	R-134a	
Rated current (A)	0.7	
Water temperature control	Thermostat	
Outside dimension (mm) (W x H x D)	303 x 994 x 402	303 x 1,044 x 402
Weight (kg)	16.4	16.6

* Detail is subject to change without prior notice.

INSTALLATION GUIDES

Location preparation.

Install the hot & cold water dispenser on a level floor to prevent vibration that may cause too much noise while operating this appliance.

Appropriate ventilation.

Locate the hot & cold water dispenser in a location where there is proper air circulation. Allow at least 10 cm. of space between the hot & cold water dispenser (at rear) and the wall in order to allow for appropriate air circulation to cool the compressor. This will help the compressor last for longer.

Install the hot & cold water dispenser in appropriate insulated area.

Install the hot & cold water dispenser in location that is properly insulated and not wet. For example, it may cover the floor with rubber liners etc. Also, keep the hot & cold water dispenser area free of water and humidity. Locate the appliance away from direct sunlight or sources of heat such as stove or oven etc.

HOW TO USE HOT & COLD WATER DISPENSER

Be sure that the rated voltage is 220V only before use.

1. Check and clean the tank cooler.
2. Place water partition and bottle support.
3. Pour water from the bottle into the tank cooler and arrange the bottle to be in the middle.

4. Plug in tightly with the wall outlet to the unit will start operating. (Cold lamp indicator shows orange light and changes to green when the cold water reaches the predetemined temperature)
5. Hot lamp indicator shows orange color when plug in. Push "ON" button (at the back of the unit and the red light is showned). The water heater starts operation and the hot lamp indicator will change to red color when the hot water reaches predetermined temperature.
6. Holder glass or container on the drain tray grate.
   - The circular shapes in the drip plate help align the flow of water. (See in the picture)
   - To avoid splashes, hold the cup as close to the tap as possible.



Note • If you want to use only the water cooler push "OFF" button to turn off the heater (at the back of the unit, the red light from hot lamp indicator is disappeared). The orange light from hot lamp indicator in the front of the unit is still shown.
- Do not turn on water heater function if there is no water in the tank.
- If the unit has not been used for a long time, turn off the water heater (OFF), unplug, take out the water bottle, and drain the left water out of the tank cooler.

Safety switch

Lock for hot water button to flow out of the hot water faucet.

How to get hot water

Push the hot water release button inward and press the control downward to start dispensing water.

How to get cold water

Press and hold the cold water button, cold water will be dispensed from the cold water faucet.

STEPS TO FILL WATER INTO THE UNIT

1. Carefully lift bottle using one hand hold at the neck of bottle and another hand hold at the bottom of bottle. (See in the picture)

2. Tilt the bottle and invert the bottle quickly. (See in the picture)

3. Place the bottle in vertical position and make sure the bottle settles properly on the hot & cold water dispenser. (See in the picture)

INSTRUCTION

Avoid using pour the water from the bottle to the tank cooler the tank cooler is full before placing the bottle on the unit. (See in the picture)

When the water is empty, and you would like to change to the new bottle of water, please follow below instructions:

1. Take out the empty bottle from the tank cooler.
2. Check the water level in the tank cooler. It should not be more then half of the tank cooler. Then place the new water bottle by following the water refill instruction 1-3.

CLEANING AND MAINTENANCE

Always unplug before cleaning.

How to drain the water out from heater tank

1. **Push OFF button to turn of water heater and unplug (do not turn off the water heater without unplugging).**
2. Take out the water bottle from the hot & cold water dispenser.
3. Prepare a proper container for the drained hot water.
4. Turn the drain valve cap to let the hot water drain out.
5. When the hot water is drained out completely, turn the drain valve cap to close tightly.



How to eliminate the plaques in tank cooler

(Water partition must not be placed in the tank cooler)

Mix the vinegar with water (1:1) for 4 litres. Pour the mixture into drinking tank cooler. Press and hold the hot water button until hot water flows down. Push "ON" button to start hot water function for about 1 hour. Then stop for another 30 minutes. Drain the water through the drainage and the 2 faucets. Refill the water to clean the tank cooler for 2 or 3 times. In genaral, plaques elimination should be done every 6 months.

Cleaning the unit

- **Cleaning outside of the unit**, use damp cloth with mild soap to clean external surface then use damp cloth with clean water to wipe the soap and dry with soft cloth again.
  Note : Avoid clean outside of the unit by using any volatile such as benzene or thinner. Some of these volatile may discolor or damage some part of the unit.
- **When condenser assembly is dirty**, The dust should be wiped out to allow the machine works at maximum efficiency.

Cleaning the parts

Drain tray

- When the water indicator rises to the highest level. (See in the picture)
- Lift the drain tray (No.1) and remove it from the front of the unit (No.2).
- Water in the drain tray must be removed; rinse and use sponge to clean then dry it with soft cloth and reassemble the drain tray into the unit.

MANUFACTURED BY WESTERN APPLIANCES CO., LTD.
97 Moo 20 Sala Daeng, Bang Nam Priao, Chachoengsao 24000

INITIAL INSPECTIONS

Please inspect the following points before calling for service.

Symptom	Check points
Water is not cold / not hot or compressor does not work / heater does not work.	• Check if the plug is tight firmly. • Check if there is problem with electricity or not. (If there is a problem with electricity, delay unit will automatically cut off the electricity for 3 minutes and then starts operating again)
Overflow water from the base.	• Check if there is too much water in the tank cooler. • Check if the water from the drain tray is leaking in the front of the unit or not.
Unit operation is noisy.	• Check if the unit is place on incline floor or not.
Water leakage, water drop, water ooze out.	• Check for any leakage at the tank cooler. • Check for cracked water bottle. • Check for any leakage or any water drop from the faucet body.
Water cannot flow properly.	• Check water in the tank cooler. Is it freeze and blocked the water outlet?

TESTING FOR WATER LEAK FROM TANK COOLER

1. Unplug the unit.
2. Remove the water bottle from the hot & cold water dispenser, drain water from the tank cooler until water remains 3/4 of the tank cooler.
3. Leave the unit for 24 hours and note whether water remains at the same level or any leakage from any parts. If the water level decreases, please inform SHARP service facility or contact SHARP company.

Sole Distributor in Thailand
THAI CITY ELECTRIC CO., LTD.
1643/4 New Petchburi Rd., Makkasan, Ratchathewi, Bangkok 10400 Tel. 0 2333 3111 Call Center 0 2254 6000
E-mail : callcenter@thaicity.co.th

www.thaicity.co.th
www.sharp-weeclub.com
sharpweeclub

ข้อแนะนำในการใช้งานเพื่อความปลอดภัย

กรุณาอ่านคำเตือน และข้อแนะนำในการใช้อย่างละเอียดก่อนการใช้งาน และปฏิบัติตามอย่างเคร่งครัด ทั้งนี้เพื่อความปลอดภัยต่อบุคคล และป้องกันความเสียหายที่อาจเกิดขึ้นกับทรัพย์สินของท่าน

- ต้องติดตั้งสายดินให้ถูกวิธีพร้อมติดตั้งเครื่องทำน้ำร้อน-น้ำเย็น
- ต้องติดตั้งเครื่องป้องกันอันตรายจากไฟฟ้ารั่ว
- ต้องติดตั้งเครื่องทำน้ำร้อน-น้ำเย็นในบริเวณที่เป็นฉนวนไฟฟ้าและไม่เปียกชื้น เช่น ปูพื้น ด้วยผ้ายาง ฯลฯ และไม่ควรให้มีน้ำขึ้นและ
- ควรตรวจสอบสภาพความปลอดภัยของเครื่องทำน้ำร้อน-น้ำเย็น โดยช่างผู้ชำนาญงานเป็นประจำอย่างน้อยทุก 6 เดือน



คำเตือน

1. หลีกเลี่ยงเสียบปลั๊กร่วมกับเครื่องใช้ไฟฟ้าอื่นๆ เพราะอาจทำให้เต้ารับเกิดความร้อน และเป็นสาเหตุทำให้เกิดไฟไหม้ได้
2. ไม่ควรถอดปลั๊กในเวลากลางคืน เพราะเครื่องมีการตัดต่อการทำงานโดยอัตโนมัติ
3. อย่าเสียบปลั๊กในขณะที่มือเปียก เพราะอาจทำให้ได้รับอันตรายจากไฟฟ้ารั่วได้
4. อุณหภูมิน้ำประมาณ 80-95 องศาเซลเซียส จึงควรใช้ความระมัดระวังเพราะอาจลวกผิวหนังท่านได้

ข้อแนะนำในการใช้ / ข้อปฏิบัติ

1. หากสายไฟหรือปลั๊กเสียบชำรุด ต้องให้ศูนย์บริการหลังการขายของชาร์ปหรือผู้ที่ผ่านการอบรมจากทางบริษัทฯ ดำเนินการตรวจสอบและซ่อมแซม เพื่อหลีกเลี่ยงความเสี่ยงและอันตรายที่อาจเกิดขึ้น
2. หากเครื่องทำงานผิดปกติ ห้ามแก้ไขด้วยตนเอง เพื่อความปลอดภัยและสามารถใช้เครื่องได้เต็มประสิทธิภาพ ควรติดต่อศูนย์บริการชาร์ปใกล้บ้านท่านเพื่อแจ้งซ่อม
3. หลีกเลี่ยงการใช้น้ำแร่ น้ำชาหรือของเหลวอื่นๆ นอกจากน้ำเปล่าในเครื่องเพราะจะทำให้เกิดคราบตะกรัน ในถังน้ำร้อนและอุดตันในหน่อยน้ำร้อนได้
4. เครื่องทำน้ำร้อน - น้ำเย็น นี้ไม่มีเจตนาให้ใช้โดยบุคคล (รวมถึงเด็ก) ที่ด้อยความสามารถทางร่างกาย ทางประสาทสัมผัสหรือจิตใจ หรือขาดประสบการณ์และความรู้ เว้นแต่ว่าได้รับการควบคุมดูแล หรือการสอนเกี่ยวกับการใช้เครื่องใช้ไฟฟ้าโดยบุคคลที่รับผิดชอบต่อความปลอดภัยของบุคคลเหล่านั้น
5. เด็กควรอยู่ในความดูแลของผู้ปกครองเพื่อให้แน่ใจว่าจะไม่เล่นผลิตภัณฑ์
6. อุณหภูมิน้ำที่ดีแช่เข้าเครื่องไม่ควรเกิน 35 องศาเซลเซียส เพราะจะทำให้เครื่องทำงานหนัก
7. เมื่อไฟฟ้าดับกระทันหันหรือไฟฟ้ากลับมาใช้งานภายในบ้านควรถอดปลั๊กออกเพื่อป้องกันมิให้คอมเพรสเซอร์เสียหาย
8. การขนส่งอาจวางตัวเครื่องแนวนอน ดังนั้นก่อนใช้งานควรตั้งทิ้งไว้ก่อนประมาณ 24-48 ชั่วโมง เพื่อให้น้ำยาในคอมเพรสเซอร์ไหลกลับระดับดังเดิม แล้วจึงเสียบปลั๊กใช้งานตามปกติ
9. การเสียบหรือถอดปลั๊กทุกครั้งควรจับที่หัวปลั๊ก อย่าดึงหรือกระชากสายไฟ เพราะอาจทำให้สายไฟชำรุดได้
10. หากถอดปลั๊กเพื่อปิดการทำงานของเครื่องและต้องการเปิดเครื่องอีกครั้ง ควรรอเวลาอย่างน้อย 3 นาที เพื่อป้องกันเครื่องเสียหาย

ส่วนประกอบ

ข้อมูลจำเพาะ

รุ่น	SB-210	SB-210S
แรงดันไฟฟ้า (โวลต์)	220	
ความถี่กระแสไฟฟ้า (เฮิรตซ์)	50	
กำลังไฟฟ้า (ฮีทเตอร์) (วัตต์)	610	
ความสามารถในการทำความร้อน (ลิตร/ชั่วโมง)	6	
ความสามารถทำความเย็น (ลิตร/ชั่วโมง)	4	
สารทำความเย็น	R-134a	
กระแสไฟฟ้าคอมเพรสเซอร์ (แอมแปร์)	0.7	
การควบคุมอุณหภูมิน้ำดื่ม	เทอร์โมสตัท	
ขนาดภายนอกของเครื่องทำน้ำร้อน-น้ำเย็น (กxลxส) (มิลลิเมตร)	303 x 994 x 402	303 x 1,044 x 402
น้ำหนักสุทธิ (กิโลกรัม)	16.4	16.6

* รายละเอียดอาจเปลี่ยนแปลงได้โดยไม่ต้องแจ้งให้ทราบล่วงหน้า

การติดตั้ง

การเตรียมสถานที่ตั้ง

ควรตั้งเครื่องในพื้นที่เรียบและสม่ำเสมอ เพื่อป้องกันการสั่น ซึ่งเป็นสาเหตุให้เกิดเสียงดังจากการทำงานของเครื่องได้

การระบายอากาศที่ดี

ควรตั้งเครื่องในที่อากาศถ่ายเทได้สะดวก ด้านหลังของเครื่องควรห่างจากผนังไม่น้อยกว่า 10 เซนติเมตร เพื่อให้เครื่องระบายอากาศร้อนได้ดี และทำให้ค่อมเพรสเซอร์มีอายุการใช้งานได้ยาวนานขึ้น

ต้องตั้งเครื่องในบริเวณที่เป็นฉนวนไฟฟ้า

ต้องติดตั้งเครื่องในบริเวณที่เป็นฉนวนไฟฟ้า และไม่เปียกชื้น เช่น ปูพื้นด้วยผ้ายาง ฯลฯ และไม่ควรให้มีน้ำขึ้นและ ไม่ควรตั้งในที่แสงแดดส่องถึง หรือในบริเวณที่มีความร้อนสูง เช่น ใกล้เตาแก๊ส หรือข้อน เป็นต้น

วิธีการใช้เครื่องทำน้ำร้อน-น้ำเย็น

ก่อนการใช้งาน ควรตรวจสอบให้แน่ใจว่าแรงดันไฟฟ้าที่ใช้คือ 220 โวลต์เท่านั้น

1. ตรวจสอบและทำความสะอาดถังเก็บน้ำ
2. ใส่ตัวกันน้ำร้อน-น้ำเย็นและที่รองรับขวดน้ำ
3. ยกขวดน้ำดื่มเพื่อ เทน้ำลงในถังเก็บน้ำและจัดขวดให้อยู่ตรงกลาง
4. เสียบปลั๊กเข้ากับเต้ารับให้แน่น เครื่องเริ่มทำงาน (ไฟแสดงการทำน้ำเย็นสีสัมผัสติดสว่างและเปลี่ยนเป็นสีเขียว เมื่อน้ำเย็นถึงอุณหภูมิที่กำหนด)
5. ไฟแสดงการทำงานสีสัมผัสติดสว่าง (เมื่อเสียบปลั๊ก) กดปุ่ม ON เปิดการทำงานน้ำร้อน (ด้านหลังเครื่องไฟสีแดงที่ปุ่มจะติดสว่าง) เครื่องเริ่มทำน้ำร้อนและไฟแสดงการทำงานน้ำร้อนจะเปลี่ยนเป็นสีแดง เมื่อน้ำร้อนถึงอุณหภูมิที่กำหนด
6. วางแก้วหรือกาชนบนตะแกรงครอบถาดรองน้ำทิ้ง
   - เครื่องหมายวงกลมบนตะแกรงครอบถาดรองน้ำทิ้งชี้ชี้เป็นตำแหน่งการไหลของน้ำร้อน
   - เพื่อหลีกเลี่ยงการกระเด็นของน้ำ ควรถือถ้วยให้ใกล้กับหัวจ่ายน้ำมากที่สุด

หมายเหตุ
- เมื่อต้องการให้เครื่องทำน้ำร้อนเพียงอย่างเดียว ให้กดปุ่ม OFF ปิดระบบทำน้ำร้อน (ตำแหน่งเครื่องไฟสีแดงปุ่มระบบทำน้ำร้อนจะดับ) ไฟแสดงการทำงานน้ำร้อนสีสัมผัสจะหายไป ยังคงติดสว่างอยู่
- ห้ามเปิดระบบทำน้ำร้อน เมื่อไม่มีน้ำในถังเก็บน้ำ
- หากไม่ได้ใช้เครื่องเป็นระยะเวลานาน ให้ปิดระบบทำน้ำร้อน (OFF) ถอดปลั๊กยกขวดน้ำออก และระบายน้ำออกจากถังเก็บน้ำ

ปุ่มนิรภัย สำหรับล็อกปุ่มกดน้ำร้อนที่จะไหลออกจากหัวจ่าย

การกดน้ำร้อน กดปุ่มนิรภัยเข้าหาเครื่องและกดปุ่มน้ำร้อนลงเครื่องเริ่มจ่ายน้ำร้อน

การกดน้ำเย็น กดปุ่มกดน้ำเย็นค้างไว้ น้ำเย็นจะไหลออกจากหัวจ่าย

วิธีการเติมน้ำดื่มที่เครื่องทำน้ำร้อน-น้ำเย็น

1. ยกขวดน้ำดื่มขึ้นมา โดยใช้มือข้างหนึ่งจับที่คอขวดและมืออีกข้างหนึ่งจับที่ก้นขวด (ดังรูป)
2. วางขวดน้ำตะแคง แล้วรีบคว่ำขวดน้ำโดยเร็ว (ดังรูป)
3. วางขวดน้ำให้อยู่ในตำแหน่งตั้งตรงไม่เอียงไปด้านใดด้านหนึ่ง (ดังรูป)

ข้อแนะนำในการเติมน้ำ

หลีกเลี่ยงการเทน้ำจากขวดน้ำลงในถังเก็บน้ำจนเต็ม แล้วจึงคว่ำขวดน้ำลงไป (ดังรูป) เมื่อน้ำในขวดน้ำหมด ต้องการเปลี่ยนควรปฏิบัติ ดังนี้

1. ยกขวดที่หมดออกจากถังเก็บน้ำ
2. ตรวจดูระดับน้ำในถังเก็บน้ำให้มีประมาณไม่เกินครึ่งถังและยกขวดน้ำใหม่ควำลง ได้ (ปฏิบัติตามวิธีการเติมน้ำ ข้อ 1-3)

วิธีทำความสะอาดและบำรุงรักษา

ควรถอดปลั๊กทุกครั้งก่อนทำความสะอาดเครื่อง

วิธีการระบายน้ำจากถังน้ำร้อน

1. **กดปุ่มปิดระบบทำน้ำร้อนที่ตำแหน่ง OFF และต้องถอดปลั๊กไฟออก (ห้ามปิดเฉพาะปุ่มระบบทำน้ำร้อน)**
2. ยกขวดน้ำดื่มออกจากเครื่องทำน้ำร้อน-น้ำเย็น
3. เตรียมภาชนะรองรับน้ำร้อนที่ระบายทิ้ง
4. หมุนจุกเพื่อเปิดทางระบายน้ำในถังน้ำร้อนทิ้ง
5. เมื่อระบายน้ำในถังน้ำร้อนออกหมดแล้ว ให้หมุนจุกปิดทางระบายน้ำให้แน่น



วิธีการขจัดตะกรันในถังน้ำร้อน

(ต้องไม่ใส่ตัวกันน้ำร้อน-น้ำเย็น ในถังเก็บน้ำ)

น้ำผ้มสามารถผสมกับน้ำ (อัตราส่วน 1:1) ปริมาณ 4 ลิตร เทลงในถังเก็บน้ำดื่มกดปุ่มกดน้ำร้อนค้างไว้ หัวจ่ายน้ำร้อนจะมีน้ำไหลออก กดปุ่ม ON เปิดระบบทำน้ำร้อนประมาณ 1 ชั่วโมง พักทิ้งไว้ประมาณ 30 นาที ระบายน้ำออกทางจุกระบายน้ำร้อนทิ้ง และหัวจ่ายน้ำทั้ง 2 หัว เติมน้ำเพื่อทำความสะอาดถังเก็บน้ำดื่มด้วยน้ำสะอาดอีก 2 หรือ 3 ครั้ง โดยปกติควรล้างขจัดคราบตะกรันน้ำเป็นประจำทุก ๆ 6 เดือน

การทำความสะอาดตัวเครื่อง

- **ภายนอกเครื่อง** เช็ดด้วยผ้านุ่มชุบน้ำสบู่อ่อนแล้วใช้ผ้าชุบน้ำสะอาดเช็ดคราบสบู่ออก จากนั้นเช็ดซ้ำอีกครั้งด้วยผ้าแห้ง

หมายเหตุ
 การทำความสะอาดภายนอกเครื่องทำน้ำร้อน - น้ำเย็น โดยใช้สารระเหยต่างๆ เช่น เบนซีนหรือทินเนอร์ อาจทำให้สีซีดลง หรือรีนส่วนพลาสติกเสียหายได้

- **แผงระบายความร้อนสปริกเ** ควรเช็ดหรือปัดฝุ่นละอองออก เพื่อให้เครื่องทำงานได้เต็มประสิทธิภาพยิ่งขึ้น

การทำความสะอาดชิ้นส่วน

ถาดรองน้ำทิ้ง

- เมื่อตัวชี้วัดระดับน้ำลอยขึ้นจนถึงระดับสูงสุด (ดังรูป)
- ยกถาดรองน้ำทิ้งซึ่ง (หมายเลข 1) แล้วดึงออกจากหน้าเครื่อง (หมายเลข 2)
- เหน้าในถาดรองน้ำทิ้ง ล้างด้วยฟองน้ำ เช็ดให้แห้ง ประกอบกลับเข้าที่ตัวเครื่อง

การตรวจสอบเบื้องต้น

โปรดตรวจสอบตามจุดต่อไปนี้ ก่อนที่จะเรียกช่างจากศูนย์บริการ

อาการ	การตรวจสอบ
น้ำไม่เย็น/ไม่ร้อนหรือคอมเพรสเซอร์ / อีทเตอร์ไม่ทำงาน	• ตรวจสอบดูว่าการเสียบปลั๊กแน่นดีหรือไม่ • ตรวจสอบไฟฟ้าขัดข้องหรือไม่ (หากไฟฟ้าขัดข้องไม่ต้องติดใจ 3 นาที จึงสามารถทำงานต่อได้)
น้ำมีออกมาที่ฐานเครื่อง	• ตรวจสอบระดับน้ำในถังเก็บน้ำมากเกินไปหรือไม่ • ตรวจสอบน้ำจากกรองน้ำที่ต่อไหลออกทางหน้าเครื่องหรือไม่
เครื่องทำงานเสียงดัง	• ตรวจสอบพื้นที่ตั้งเครื่องไม่ได้ระนาบเอียงหรือไม่
น้ำร้อน น้ำหยดหรือน้ำซึม	• ตรวจสอบถังเก็บน้ำร้วหรือไม่ • ตรวจสอบขวดน้ำร้วหรือไม่ • ตรวจสอบว่ามีน้ำร้วหยดจากหัวจ่ายน้ำหรือไม่
น้ำไหลออกไม่สะดวก	• ตรวจสอบน้ำในถังเก็บน้ำเป็นน้ำแข็งจุดต้นทางออกหรือไม่

ผลิตโดย บริษัท เวสเทอร์น แอพไพลแอนซ์ จำกัด
97 หมู่ 20 ตำบลคลาแดง อำเภอบางน้ำเปรี้ยว จังหวัดฉะเชิงเทรา 24000

การทดสอบน้ำร้วจากถังเก็บน้ำ

1. ถอดปลั๊กไฟออก
2. นำขวดน้ำที่ควำบนเครื่องทำน้ำร้อน-น้ำเย็นออก กดน้ำที่อยู่ในถังเก็บน้ำให้ระดับน้ำเหลือประมาณ 3 ใน 4 ของถังเก็บน้ำ
3. ปล่อยทิ้งไว้ประมาณ 24 ชม. สังเกตว่าน้ำยังคงอยู่ในระดับเดิมหรือร้วออกมาบริเวณใต หากปริมาณน้ำลดลงให้แจ้งศูนย์บริการชาร์ปใกล้บ้านท่าน เพื่อแจ้งซ่อม

ศูนย์บริการและศูนย์อะไหล่
บริษัท กรุงไทยการไฟฟ้า จำกัด

หมายเหตุ หากไม่สามารถติดต่อศูนย์บริการ/ศูนย์อะไหล่ หรือมีปัญหาเรื่องการบริการกรุณาติดต่อ แผนกบริการ บริษัท กรุงไทยการไฟฟ้า จำกัด โทร. 0 2333 3111 ต่อ 209, 210

เราได้ย้าย
การให้บริการทางการค้าทุก
ท่านสามารถติดต่อผ่านช่องทาง Social Commerce ของเราได้ที่
WWW.THAICITYASSOCIAL.COM

ประสาน **บริษัท กรุงไทยการไฟฟ้า จำกัด**
1/4/24 ถนนพระรามที่ 6 แขวงสามเสนใน เขตพระนคร กรุงเทพฯ 10400
โทร.0 2333 3111 ศูนย์ลูกค้าสัมพันธ์ 0 2254 5000
อีเมล : callcenter@thaicity.co.th

www.thaicity.co.th
www.sharp-weeclub.com
sharpweeclub

SHARP

คู่มือการใช้งาน



เครื่องทำน้ำร้อน-น้ำเย็นชาร์ป

รุ่น SB-210
SB-210S

สารบัญ

	หน้า
ข้อแนะนำในการใช้งานเพื่อความปลอดภัย	2-3
ส่วนประกอบ	4
ข้อมูลจำเพาะ	4
การติดตั้ง	5
วิธีการใช้เครื่องทำน้ำร้อน-น้ำเย็น	5-6
วิธีการเติมน้ำดื่มที่เครื่องทำน้ำร้อน-น้ำเย็น	6
วิธีทำความสะอาดและบำรุงรักษา	6-7
การตรวจสอบเบื้องต้น	7
การทดสอบน้ำร้วจากถังเก็บน้ำ	8
ศูนย์บริการและศูนย์อะไหล่	8

โปรดดูวันผลิตที่ตัวสินค้า

บริษัทฯ ขอขอบพระคุณที่ท่านได้ความไว้วางใจในผลิตภัณฑ์ของบริษัท กรุงไทยการไฟฟ้า จำกัด เพื่อให้การใช้เครื่องทำน้ำร้อน-น้ำเย็นชาร์ปเป็นไปอย่างมีประสิทธิภาพ กรุณาอ่านคู่มือการใช้อย่างละเอียดก่อนการใช้งาน

REV.1-2566